

MOVE PRO

The most accurate
technology ever implemented
in an equine sensor.



KEY STEPS TO HAVE ACCURATE DATA

1. HAVE A STRONG GPS SIGNAL

- Turn on the sensor in an outdoor space and wait for the pink LED to stop blinking.
- Walk without stopping for two minutes before starting to record.

2. FASTEN THE SENSOR HOLDER ON YOUR GIRTH

- Place the sensor holder correctly so it does not move even while your horse is in motion.
- Make sure that the sensor holder is positioned at the centre of the girth.
- Check that the girth is evenly tightened on both sides so as to secure the sensor on your horse.



Find out more about
Alogo's Move Pro use here.



www.alogo.io